

Installation Instructions for: Header Tether Kits (NHRA Accepted)

Read All of the Instructions Before Beginning the Installation.

To get the most out of your NEW Tether Kit, follow these installation recommendations:

Mounting Instructions:

- 1) Before installing tether, make sure engine is stopped and completely cooled before working on exhaust.
- 2) Find primary tube clamp location, making sure to use a tube that is straight and **NOT** on a bend. Install clamp but do not install locking nut at this time.
- 3) Find collector tube clamp location, making sure to use the straightest portion of collector. Merge-style collector must be installed at the throat area. Install clamp but do not install locking nut at this time.
- 4) **If using our optional tether brackets**, they will be installed by slipping bracket over the end of the T-bolt making sure that the etched logo is facing up. Install your locking nuts to both clamps but do not tighten at this time. Remove the shoulder bolt from aluminum tether bracket. Place looped end of tether between bracket and re-install shoulder bolt. Adjust tether so it has a small amount of play and is not taut. Once it is to your liking, install the locking nuts to both clamps and tighten. **Be sure not to overtighten.**
- 5) **If not using optional tether bracket**, slip the looped end of the tether over the T-bolt before the bolt is pushed through the trunnion. Make sure to tuck the cable between the T-bolt and clamp towards the **threaded** end. Adjust tether so it has a small amount of play and is not taut. Once it is to your liking, install the locking nuts to both clamps and tighten. **Be sure not to overtighten.**

Parts List:

- 2- Primary tube clamps
- 2- Collector tube clamps
- 2- Tethers
- 2- Tether brackets (optional)



Picture above w/optional brackets



Picture above w/o optional brackets



215-969-3550
www.prpracingproducts.com
www.facebook.com/prpracingproducts

