

# Installation Instructions for: Dragster Scoop Mount

Read All of the Instructions Before Beginning the Installation.

To get the most out of your scoop mount, follow these installation recommendations: **Note** – This kit is equipped with all the necessary hardware to mount your scoop tray.

## Mounting Instructions:

1. The first step is to pre-assemble the bracket before installation. Install the four hex shaped stand-offs on to bracket using supplied hardware. Fasten to the plate from the underside. A drop of Red Loctite thread locker is recommended.
2. Install supplied return spring and cable brackets using supplied 1/4" washers and button head screws.
3. Install 4-hole flange gasket over manifold stud bolts (Not Included).
4. Slide pre-assembled adapter plate over manifold stud bolts, followed by another 4-hole flange gasket (Not Included).
5. Install carburetor over manifold stud bolts. Tighten down in a criss cross pattern no tighter than 60 in-lbs. (Not Included).
6. Install the rear cable mount to the bracket with the supplied attaching screw. Do not tighten at this time to allow for adjustment later.
7. Units with the return spring feature should be installed now with the supplied attaching screw. Do not tighten at this time.
8. Method A: Holley 4150/4160 & Edelbrock. Install the carburetor linkage return spring bracket to the carburetor linkage by placing it between the linkage and the carburetor main body. Use a drop of Red Loctite on the threads and tighten only enough to allow the arm to pivot freely. Caution – Allow the Loctite to dry thoroughly prior to use. Method B: Holley
9. 4150/4160 & Edelbrock. Utilize the same procedure as outlined above, use Holley # 20-37 or Edelbrock # 350-8009. This will double as the mounting screw and cable attachment.
10. For the Holley Dominator install the carburetor linkage return spring bracket to the carburetor linkage upper hole by placing it between the linkage and the carburetor main body. Use a drop of Red Loctite on the threads and tighten only enough to allow the arm to pivot freely. Caution - Allow the Loctite to dry thoroughly prior to use.
11. The final adjustment to the cable is to allow for the full range of operation and to secure the fastener(s).
12. Units with the return spring feature, adjust to the required tension and secure the fastener.
13. Place air cleaner gasket onto carburetor (Not Included).
14. Install scoop tray over stand-offs and tighten using the four supplied button head screws.
15. Install nitrous solenoids on the top side of bracket using supplied hardware. **Note:** Nitrous mounting only available on adapter brackets that include the mount.

## **Parts List:**

- (1) Adapter Bracket
- (4) Pre-assembled stand-offs w/hardware
- (1) Morse cable mount
- (1) Return spring mount
- (4) #10 Flat Washers **Note:** Only with brackets that include nitrous mounting
- (4) #10-32 X 1/2" button head screws **Note:** Only with brackets that include nitrous mounting



215-969-3550  
[www.prpracingproducts.com](http://www.prpracingproducts.com)  
[www.facebook.com/prpracingproducts](http://www.facebook.com/prpracingproducts)

