

Installation Instructions for: Nitrous Switch 4500

Note: Designed for 4500 style carburetors. This includes Holley® HP series, and Quick Fuel Technology Pro Series Dominator Series carburetors.

1. Install the bracket and the switch on the side opposite the throttle linkage and onto the front carb stud and tighten the nut.
2. Test the switch for activation by moving the throttle to wide open. The standard holley 4500 series carb utilizes the bottom set of holes on the bracket for the micro switch. The Holley 4500 HP series carb will utilize the top set of mounting holes. You should hear a click from the switch indicating activation. An alternate test method would be to use a voltage/ohm meter.
3. Be sure to check the carburetor secondary bracket for alignment No binding of any sort should be present.
6. Wiring is achieved by a normally closed or normally open method along with the common for ground (**NOTE:** Only two of the three terminals are utilized.)



215-969-3550
www.prpracingproducts.com
www.facebook.com/prpracingproducts

